

wince 程序使用注意事项:

- 1、features 要加入 "Shell and User Interface" -> "User Interface" -> "Touch Display (Stylus)";
- 2、环境变量要设置 `BSP_NOTOUCH = 0`;

You can include the Touch Screen (Stylus) feature in your platform by choosing the feature from the Catalog. Choosing the Touch Screen (Stylus) feature sets the appropriate environmental variable for enabling the feature.

The following table shows the environmental variable that enables the Touch Screen (Stylus) features.

Environment variable	Description
<code>SYSGEN_TOUCH</code>	When this variable is set, the Touch Screen (Stylus) feature is included in the OS image.
	When this variable is not set, the Touch Screen (Stylus) feature is excluded from the image.

3、校准的时候要一直按下直到校准十字图标移到另一个校准点时抬起,重复同样的操作知道校准完成.采用 5 点校准(左上,右下,右上,左下,中间).如果 5 个点都触摸完成之后又让校准第一个点,那说明校准程序认为触摸点的精度没有达到要求,需要重新校准.校准完成之后可以双击触摸屏或者按 OK 键退出校准程序,校准过程中可以按 Esc 键退出校准程序;

4、如果在控制面板中没有笔针图标(Stylus),很可能是环境变量 `BSP_NOTOUCH = 0` 没有设置;

5、标准的触摸屏操作是没有光标跟随的,如果在桌面进行拖动操作的话应该有虚线矩形框.其他操作和用鼠标操作一样能执行,只是看不到光标出现;

6、如果采用 RAM-BASE 的注册表,因为校准参数保存到 RAM 中,调电之后 RAM 中的数据会丢失,所以每次重新开机后都要进行校准操作;

7、鼠标的延时右键功能需要加入相应的组件.